

封面

封底



US UK Dear user Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules. 1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty. 1	Button Instructions 1. Left button. 2. Right button. 3. Scroll wheel(Click as middle button). 4. Side button, defaulted forward. 5. Side button, defaulted backward. 6. DPI + (default). 7. DPI - (default). 8. BT pairing button. 9. Mode/Power switch. 2	Quick start guide Wired Connection [2.4G/OFF/BT] switch on "OFF", connect the mouse to computer with USB cable. The computer will recognize and configure the mouse automatically and charging mouse battery. 2.4G Wireless Connection 1. [2.4G/OFF/BT] switch on "2.4G". 2. Plug the USB receiver into USB port on your computer, the computer will recognize and configure the mouse automatically. Tip: If auto-connection unsuccessfully, or you want to connect to new device, plug out the USB receiver, press and hold [1]+[2]+[3] for 3 seconds, the LED flashes in Green, plug the USB receiver into computer USB port, the mouse will re-connect. BT Connection 1. [2.4G/OFF/BT] switch on "BT". 2. Press [8] for 3 seconds, the mouse entered pairing status. Turn on the PC BT function and searching for available devices, it will find "BT5.1 Mouse" device. Select the device to pair, after paired you can start use the mouse. Power save function The mouse will enter power save mode when it is out of operation over 2 minutes, move mouse or click any button to wake it up. 3	How to recharge the battery 1. Low battery warning---the scroll wheel LED will twinkling in red when the battery is low. 2. Use the USB cable to connect to PC USB port to charge the battery, the scroll wheel LED will steady on in red, after battery fully charged the LED turns to current DPI color. Warning:Charging current: 5V ≐ 2Amax. DPI adjustment and indication Default: DPI& indicator color(scroll wheel LED breathing lighting) 1. RED ----- 800 DPI 2. BLUE ----- 1200 DPI 3. GREEN ----- 1600 DPI 4. CYAN ----- 2400 DPI 5. PURPLE ----- 4800 DPI Report rate adjustment The mouse support adjust report rate [125Hz-250Hz-500Hz-1000Hz],when the computer didn't install software, press& hold [3], then press [3] to cycling switch report rates, the LED will flash in White to indicating current report rate: 125Hz: LED flash 1 time. 250Hz: LED flash 2 times. 500Hz: LED flash 3 times. 1000Hz: LED flash 4 times. When the computer installed software, you can use mouse software to set the report rate. 4	Backlight adjustment Press& hold [3], then press [5] to cycling switch defaulted 6 backlight effects. For more adjustable function & macro recording, please download& install mouse software to enable more possibility. Built-in Li-thion battery 1 unit. FAQ 1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports. 2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended. 5	FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. 6
BATTERY SAFETY GUIDELINES DO NOT replace the battery with a different model. DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material. DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes. DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition. DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations. DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful. CAUTION Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock. Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. 7	PT Prezado usuário, Obrigado por escolher a marca REDRAGON. Para proteger seus direitos e oferecer um melhor atendimento ao cliente, pedimos que você observe as regras da nossa garantia. 1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos. 2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia. 8	Instruções dos botões 1. Botão esquerdo 2. Botão direito 3. Botão da rodinha (clicado como botão do meio) 4. Botão lateral, avança por padrão 5. Botão lateral, volta por padrão 6. DPI + (padrão) 7. DPI - (padrão) 8. Botão de pareamento do BT 9. Chave de modo/energia 9	Guia de início rápido Conexão com fio Coloque a chave [2.4G/OFF/ BT] na posição "OFF" e conecte o mouse ao computador com o cabo USB. O computador vai reconhecer e configurar o mouse automaticamente e carregar a bateria. Conexão sem fio 2.4 G 1. Posicione a chave [2.4G/OFF/BT] em "2.4G". 2. Conecte o receptor USB na porta USB do seu computador, o computador reconhecerá e configurará o mouse automaticamente. Dica: Se a conexão automática não for bem-sucedida, ou se você quiser conectar a outro dispositivo, desconecte o receptor USB, pressione e segure [1]+[2] por 3 segundos. O LED piscará na cor verde. Conecte o receptor USB à porta USB do computador e o mouse reconectará. Conexão BT 1. Chave [2.4G/OFF/BT] em "BT". 2. Pressione [8] por 3 segundos para o mouse entrar em modo de pareamento. Ative a função BT do PC e procure por dispositivos disponíveis. Será encontrado o dispositivo "BT5.1 Mouse". Selecione o dispositivo para parear. Após o pareamento você poderá usar o mouse. Função de economia de energia O mouse entrará no modo de economia de energia após ficar inativo mais de 2 minutos. Mova o mouse ou clique em qualquer botão para ativá-lo. 10	Como recarregar a bateria 1. Aviso de bateria fraca --- O LED da rodinha piscará em vermelho quando a bateria estiver baixa. 2. Use o cabo USB para conectar à porta USB do PC para carregar a bateria. O LED da rodinha ficará vermelho. Quando a bateria estiver completamente carregada, o LED mudará para a cor atual do DPI. Aviso: Corrente de carregamento:5V ≐ 2A máx Ajuste e indicação de DPI DPI padrão e cor do indicador (iluminação oscilante do LED da roda de rolagem) 1.VERMELHO --- 800 DPI 2.AZUL --- 1200 DPI 3.VERDE --- 1600 DPI 4.CIANO --- 2200 DPI 5.ROXO --- 4800 DPI Ajuste da velocidade de leitura O mouse é compatível com ajuste da velocidade de leitura [125Hz, 250Hz, 500Hz, 1000Hz]. Se o computador não tiver o software instalado, pressione e segure [3], depois pressione [4] para alternar entre as velocidades de leitura. O LED piscará em branco para indicar a velocidade de leitura atual: 125Hz: LED pisca 1 vez. 250Hz: LED pisca 2 vezes. 500Hz: LED pisca 3 vezes. 1000Hz: LED pisca 4 vezes. Se o computador tiver o software instalado, utilize o software do mouse para configurar a velocidade de leitura. 11	Ajuste da retroiluminação: Pressione e segure [3], depois pressione [5] para alternar entre os seis efeitos de retroiluminação padrão. Para mais funções ajustáveis e gravação de macros, baixe e instale o software do mouse para ativar mais possibilidades. Bateria de íon de lítio embutida, 1 unidade. Dúvidas frequentes 1. Se o mouse não estiver respondendo, verifique se o mouse está conectado corretamente na porta USB correspondente do computador ou experimente usar outra porta USB. 2. Se o cursor estiver se movimentando lentamente, saltando ou com movimentos intermitentes, experimente outra superfície. Superfícies escuras, sujas, irregulares ou brilhantes podem afetar o desempenho do mouse. É recomendado o uso de um mouse pad. 12

型号	红龙M602P-KS 2880	备注：尺寸：L100*W100mm 材质：80g书写纸，风琴折页，正反印 印刷：单色	
名称	说明书(英+巴西)		
日期	2025-6-6		
页码	1 OF 1	文件编号	
绘图	吴九香	审核	香敏琪
		核准	
			版本
			A.0